

The operating instructions of Bluetooth setting tools

▲Notes:

1. Set the Bluetooth name can not exceed 20 bytes.
2. Bluetooth pairing password settings can not be more than 10 bytes.
3. Select the printer's version and the Bluetooth device's kind, and you can get the information from the self-test page of printer.
4. When using this tool to ensure the Bluetooth device in a disconnected status.
- 5, Please ensure the IP of printer and computer are both in the same network segment.

▲This tool can be setting the related functions of our MINI Bluetooth Printers:

- 1.Modify the Bluetooth device name;
- 2.Modify and query the Bluetooth device pairing password;
- 3.Modify and query the Bluetooth baud rate;
4. Printer IP, Gateway, Subnet mask, MAC address, Cutter, Buzzer, Restore factory default setting, Self-test page print, Print density level and Print mode.

▲Instructions as shown in figure:

Printer Tools_V3.1

Printer Tools

Interface Setting 1
Port: Baud Rate: 2 Printer IP:

Function Set
Version choice:
BT postion:
Bluetooth name set:
Pairing password set:

Baud rate:

 3

Printer internet
IP:
Subnet mask:
GateWay:
MAC:

Function Set

 4

Explain:
1. Set the bluetooth name can not exceed 20 bytes.
2. password setting can not be more than 10 bytes.
3. The bluetooth device disconnected state.
4. ZOX: from Z01 to Z04; XX: Random two Alphabets.
5. You can get the version from the selftest page.

Step 1:

Set port , please choose “USB” , the factory default printer with standard USB cable;

Step 2:

Click “Connection” ;

Step 3:

1. According to the printer's self-test page, select the printer's version and the Bluetooth device's kind;
2. According to the need to set up the Bluetooth printer name, enter within the dialog, determined to set the name, then Click on the "Name set";
3. According to the need to set up the Bluetooth printer pairing password, input within the dialog, confirmed after pairing set password, please click "password set", if you want to query pairing password, please click "Pairing password query";
4. According to the need to set up the Bluetooth baud rate, determined to set the baud rate, then click on "baud rate set", if you want to query the baud rate setting is correct, click "baud rate query";

Step 4:

Set after the completion of the click "Exit" window, you can turn off the tool;

▲ The operating instructions of relevant parameter modify for printer IP and functions.

Printer Tools_V3.1

Printer Tools

Interface Setting 1
Port: Ethernet Baud Rate: 115200 Disconnection 2 Printer IP: 192 . 168 . 1 . 100

Function Set
Version choice: 58.C/E-ZOX-XX
BT position: BT Position1
Bluetooth name set: Name Set
Pairing password set: Password Set
Password Query
Baud rate: 9600 Baud Rate Set
Baud Rate Query
Hex Send

Printer internet
IP: 192 . 168 . 1 . 100 MODIFY
Subnet mask: 255 . 255 . 255 . 0 MODIFY
GateWay: 192 . 168 . 1 . 1 MODIFY
MAC: 11 1F E0 13 2D 0C MAC MODIFY 3

Function Set 4
Print Mode: ASCII Factory Reset
Beep Set: ON Selftest Page
Cutter Set: ON
Print Density: Level3_Dark
Serial Baud: 115200
Font Set: Font_1

5
EXIT

Explain:
1. Set the bluetooth name can not exceed 20 bytes.
2. password setting can not be more than 10 bytes.
3. The bluetooth device disconnected state.
4. ZOX: from Z01 to Z04; XX: Random two Alphabets.
5. You can get the version from the selftest page.

Step 1:

Select the port " Ethernet ", and get the printer IP from Self-test page.
(the default IP address is 192.168.1.100)

Printer Tools

Interface Setting
Port: Ethernet Baud Rate: 115200 Connection Printer IP: 192 . 168 . 1 . 100

Step 2:

Click the "Connection", if success, it will be shown " Disconnection".

Step 3:

**Can be modified the relevant parameter of printers (IP, Subnet mask, Gateway, MAC),
After all the setting are done, please power off and restart the printer.**

Step 4:

**About the printer “Function Set”, you can set Print Mode (Chinese/ASCII), Beep Set (ON/OFF), Cutter set (ON/OFF), Print Density (Level 1 to Level 4), Serial Baud Rate (9600, 19200, 38400, 57600, 115200), Front set (Front_1, Front_2 and Front_3,).
After all the setting are done, please power off and restart the printer.**

Step 5:

**You also can do the “Factory Reset” and print the “Self-test page” by this tool.
If all is done, please click “ EXIT” to close the tool.**